


Quality United Brass Replacement Parts

HF70 Head Valve


HF-70 Head Valve used on foot and air-operated pressing machines. An improved packless valve which can be used to replace all other model head valves



Part No.	Part Name
HF70-1	Body
HF70-2	Body Lock Nut
HF70-3	Copper Gasket
HF70-4	Bracket
HF70-5	Bracket Bolt
HF70-6	Handle Long
H 70-8	Wood Handle
HF70-9	Spring
HF70-10	Stop Screw
HF70-11	Spring Screw
HF70-12	Fingertip Pad
HF70-13	Pad Screws
H 70-14	Wood End Only
HF70-15	Short Offset Handle
HF70-16	Cotter Pin
HF70-17	Disc Holder
HF70-18	Disc only
HF70-19	Valve Stem
HF70-20	Stem Guide
HF70-21	Stem Washer
HF70-22	Bracket Pin
HF70-23	Handle Long-Air

MODEL HF70 with LONG FINGERTIP HANDLE
 MODEL HFS70 with SHORT OFFSET FINGERTIP HANDLE
 MODEL H70 with WOOD HANDLE

B50 Buck Valve



New York BL-50 Buck Valve used on New York foot and air operated pressing machines. A packless valve available with long shank (BL-50) and short shank (BS-50), for other make presses.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
14600-1L	Body- 4-5/8" Long	14600-3L	Valve Stem 2 3/4" Long	14600-5	Body Lock Nut
14600-1S	Body- 3 3/4" Long	14600-3S	Valve Stem 1 3/4" Long	14600-6	Guide Lock Nut
14600-2	Disc Holder Assembly	14600-4	Stem Guide	14600-7	Gasket

All replacement steam press parts warranted for one year by Seickel & Sons Inc.

Seickel & Sons Inc. is not affiliated with Hoffman/New Yorker Inc. and does not rely on Hoffman/New Yorker Inc. for its replacement parts.

SEICKEL & SONS INC.

MANUFACTURERS & REBUILDERS OF STEAM PRESSING EQUIPMENT

360 ELIZABETH AVE., NEWARK, NJ 07112 TEL. 973-242-1948 FAX 973-733-4956
 315 WEST 36TH ST., SUITE 504, NY, NY 10018 TEL. 212-290-2120 FAX 212-290-2140
 TOLL FREE IN U.S. 1-800-338-5044

WEB WWW.SEICKEL.COM

SALES@SEICKEL.COM